

DE: Beiblatt Schaltgerät 230V für Pumpstationen *Retrofit M*

i Technischer Hinweis!

Der Anlage beiliegende Dokumentation (010-910) ist zu beachten.

Aufgrund der Einzelanfertigung der Pumpstationen *Retrofit M* sind bei Inbetriebnahme des Schaltgerätes Konfigurationen vorzunehmen. Die zu wählenden Menüpunkte für Ihren vorliegenden Artikel ist, entsprechend der Artikelnummer, der nachfolgenden Dokumentation zu entnehmen.

Bei den Pumpen GTF600 bitte folgende Menüpunkte am Schaltgerät einstellen:

- |3.4. Anlagen-Konfiguration|
- => |3.4.8 Pumpstation S GTF600|
- ▶ Bei Variante mit Tauchglocke (Art.-Nr.: 8744000) unter Menüpunkt
 - |3.5 Sensorkonfiguration|
 - => |3.5.1 Drucksensor+Optische-Sonde| auswählen.
- ▶ Bei Variante mit Schwimmerschalter (Art.-Nr.: 8744001) unter Menüpunkt
 - |3.5 Sensorkonfiguration|
 - => |3.5.7 Schwimmer| auswählen.

Bei den Pumpen GTF1000 bitte folgende Menüpunkte am Schaltgerät einstellen:

- |3.4. Anlagen-Konfiguration|
- => |3.4.9 Aquapump XL GTF1200|
- ▶ Bei Variante mit Tauchglocke (Art.-Nr.: 8744002) unter Menüpunkt
 - |3.5 Sensorkonfiguration|
 - => |3.5.1 Drucksensor+Optische-Sonde| auswählen.
- ▶ Bei Variante mit Schwimmerschalter (Art.-Nr.: 8744003) unter Menüpunkt
 - |3.5 Sensorkonfiguration|
 - => |3.5.7 Schwimmer| auswählen.

Bei den Pumpen GTF1200 bitte folgende Menüpunkte am Schaltgerät einstellen:

- |3.4. Anlagen-Konfiguration|
- => |3.4.9 Aquapump XL GTF1200|
- ▶ Bei Variante mit Tauchglocke (Art.-Nr.: 8744004) unter Menüpunkt
 - |3.5 Sensorkonfiguration|
 - => |3.5.1 Drucksensor+Optische-Sonde| auswählen.
- ▶ Bei Variante mit Schwimmerschalter (Art.-Nr.: 8744005) unter Menüpunkt
 - |3.5 Sensorkonfiguration|
 - => |3.5.7 Schwimmer| auswählen.

Bei den Pumpen GTF1250 bitte folgende Menüpunkte am Schaltgerät einstellen:

- |3.4. Anlagen-Konfiguration|
- => |3.4.18 Aqualift S200 l|
- ▶ Bei Variante mit Tauchrohr (Art.-Nr.: 8744006) unter Menüpunkt
 - |3.5 Sensorkonfiguration|
 - => |3.5.12 Drucksensor| auswählen.
- ▶ Bei Variante mit Schwimmerschalter (Art.-Nr.: 8744007) unter Menüpunkt
 - |3.5 Sensorkonfiguration|
 - => |3.5.7 Schwimmer| auswählen.

Bei den Pumpen GTF1400 bitte folgende Menüpunkte am Schaltgerät einstellen:

- |3.4. Anlagen-Konfiguration|
- => |3.4.13 Aquapump XL GTF 1400|
- ▶ Nur Variante mit Pegelsonde (Art.-Nr.: 8744020)

EN: Supplement for the 230 V control unit for pumping stations *Aquapump M*

i Technical note!

Observe the documentation (010-910) enclosed with the system.

Due to the individual production of the pumping stations *Aquapump M*, configurations must be defined when commissioning the control unit. The menu items to be selected for your article can be found in the following documentation according to the article number.

Please set the following menu items on the control unit for the pumps GTF600:

- |3.4. System configuration|
- => |3.4.8 Pumping station S GTF600|
- ▶ For the version with a submersible pressure switch (art. no. 8744000) under menu item
 - |3.5 Sensor configuration|
 - select => |3.5.1 Pressure sensor+optical probe|.
- ▶ For the version with a float switch (art. no. 8744001) under menu item
 - |3.5 Sensor configuration|
 - select => |3.5.7 Float switch|.

Please set the following menu items on the control unit for the pumps GTF1000:

- |3.4. System configuration|
- => |3.4.9 Aquapump XL GTF1200|
- ▶ For the version with a submersible pressure switch (art. no. 8744002) under menu item
 - |3.5 Sensor configuration|
 - select => |3.5.1 Pressure sensor+optical probe|.
- ▶ For the version with a float switch (art. no. 8744003) under menu item
 - |3.5 Sensor configuration|
 - select => |3.5.7 Float switch|.

Please set the following menu items on the control unit for the pumps GTF1200:

- |3.4. System configuration|
- => |3.4.9 Aquapump XL GTF1200|
- ▶ For the version with a submersible pressure switch (art. no. 8744004) under menu item
 - |3.5 Sensor configuration|
 - select => |3.5.1 Pressure sensor+optical probe|.
- ▶ For the version with a float switch (art. no. 8744005) under menu item
 - |3.5 Sensor configuration|
 - select => |3.5.7 Float switch|.

Please set the following menu items on the control unit for the pumps GTF1250:

- |3.4. System configuration|
- => |3.4.18 Aqualift S200 l|
- ▶ For the version with an immersion pipe (art. no. 8744006) under menu item
 - |3.5 Sensor configuration|
 - select => |3.5.12 Pressure sensor|.
- ▶ For the version with a float switch (art. no. 8744007) under menu item
 - |3.5 Sensor configuration|
 - select => |3.5.7 Float switch|.

Please set the following menu items on the control unit for the pumps GTF1400:

- |3.4. System configuration|
- => |3.4.13 Aquapump XL GTF 1400|
- ▶ Only the version with a level probe (art. no. 8744020)